



Type	RTS 0100	RTS 0101	RTS 0102
A	753	863	963
B	400	490	590
D	825	825	825
E	570	570	570
G	306	306	306
H	591	591	591
H1	627	627	627
L	641	641	641
Y	490	490	490
Y1	545	655	755
X	426	426	426
X1	330	440	540